



ENDF/B-VI HE-4

Principal cross sections




ENDF/B-VI HE-4

Heating




ENDF/B-VI HE-4 Damage




ENDF/B-VI HE-4

Principal cross sections




ENDF/B-VI HE-4

Heating



ENDF/B-VI HE-4

Damage



ENDF/B-VI HE-4
angular distribution for elastic

