### **Experimental Fission Research at the Gaerttner LINAC Center at Rensselaer Polytechnic Institute**

Y. Danon, Z. Blain

Gaerttner LINAC Center, Rensselaer Polytechnic Institute, Troy, NY 12180



LANL FIESTA Fission Workshop, Sep. 10 - 12, 2014





# **Collaboration (fission related)**

- RPI
  - PI: Y. Danon, Professor, Director Gaerttner LINAC Center, Nuclear Engineering Program Director
  - Graduate Students: Z. Blain, N. Thompson, D. Williams, A. Daskalakis, B. McDermott, A. Youmans
  - Undergraduate students: K. Mohindroo, Amanda Lewis
- KAPL
  - Dr. T. Donovan, Dr. G. Leinweber, Dr. D. Barry, Dr. M. Rapp, Dr. R. Block, B. Epping
- LANL (fission / LSDS)
  - Dr. R. Haight, Dr. P. Talou
- ORNL (sample for LSDS measurements)
  - Dr. Romano



*The authors thank the Stewardship Science Academic Alliance for their funding of this research, grant numbers:* DE-NAOOO1814, DE-FG03-03NA00079, DE-FG52-06NA26202, DE-FG52-09NA29453





### The Nuclear Data Program at the Gaerttner LINAC Center at RPI

- Driven by a 60 MeV pulsed electron LINAC ~ 10<sup>13</sup> n/s
- Neutron transmission
  - Resonance region: 0.001 eV- 1000 keV,
  - High energy region: 0.4- 20 MeV
- Neutron Capture
  - Resonance region: 0.01-1000 eV
- Neutron Scattering
  - High energy region: 0.4 MeV- 20 MeV
- LSDS
  - Assay of used nuclear fuel
- Prompt Fission neutron spectrum
- LSDS
  - Fission cross section and fission fragment spectroscopy.
  - (n, $\alpha$ ), (n,p) and (n, $\gamma$ ) cross sections on small (radioactive) samples.
- Support from various DOE offices
- Started a major refurbishment project ( ~\$10M)







### Focus on

- Historical Perspective
- Lead Slowing Down Spectrometer (LSDS)
  - Simultaneous measurements of fission cross section and fission fragment mass and energy distributions of small samples.
- Time-of-Flight and gamma tagging
  - Measurements of fission neutron spectra (also < 1 MeV) as a function of the incident neutron energy using a gamma tag.
  - Fission cross section using a gamma tag.







Gaerttner LINAC Center

### Early Fission Related Work at RPI Cross Section Measurements and PFN multiplicity

- <sup>232</sup>Th
  - Nakagome, Y., Block, R.C., Slovacek, R.E. and Bean, E.B., "Neutron-Induced Fission Cross Section of <sup>232</sup>Th from 1 eV to 20 keV," Physical Review C, Vol. 43, No. 4, April, 1991.
- <sup>233</sup>U
  - Weston, L.W., Gwin, R., de Saussure, G., Ingle, R.W., Todd, J.H., Craven, C.W., Hockenbury, R.W. and Block, R.C., "Neutron Fission and Capture Cross-section Measurements for Uranium-233 in the Energy Region 0.02 to 1 eV," Nuclear Science and Engineering, 42, 143-149, 1970.
- <sup>235</sup>U
  - Kaushal, N.N., Malaviay, B.K., Becker, M., Burns, E.T. and Gaerttner, E.R., "Measurement and Analysis of Fast Neutron Spectra in Uranium Depleted in the Uranium-235 Isotope," Nuclear Science and Engineering, Vol. 49, n 3, p. 330-48, November, 1972.
- <sup>238</sup>U
  - Slovacek, R.E., Cramer, D.S., Bean, E.B., Valentine, J.R., Hockenbury, R.W. and Block, R.C., "<sup>238</sup>U(n,f) Measurements Below 10 keV," Nuclear Science and Engineering, 62, 455-462, 1977.
- <sup>239,240,241</sup>Pu
  - Weinstein, S. and Block, R.C., "Neutron Multiplicity-Spin State Correlations for <sup>239</sup>Pu Resonances," Physical Review Letters, Vol. 22, No. 5, 195-198, February, 1969.
  - Gwin, R., Weston, L.W., Saussure de, G., Ingle, R.W., Todd, J.H., Gillespie, F.E., Hockenbury, R.W. and Block, R.C., "Simultaneous Measurement of the Neutron Fission and Absorption Cross Sections of Plutonium-239 Over the Energy Region 0.02 eV to 30 keV," Nuclear Science and Engineering, 45, 25-36, 1971.
  - Hockenbury, R.W., Moyer, W.R. and Block, R.C., "Neutron Capture, Fission, and Total Cross Sections of Plutonium-240 from 20 eV to 30 keV," Nuclear Science and Engineering, 49, 153-161, 1972.
  - M. S. Moore, O. D. Simpson, and T. Watanabe, J. E. Russell and R. W. Hockenbury, Fission Cross Section of Pu-241, Phys. Rev. 135, B945–B952 (1964).
- <sup>244,246,247,248</sup>Cm, <sup>254</sup>Es
  - Maguire, Jr., H.T., Stopa, C.R.S., Block, R.C., Harris, D.R., Slovacek, R.E., Dabbs, J.W.T., Dougan, R.J., Hoff, R.W. and Lougheed, R.W., "Neutron-Induced Fission Cross-Section Measurements of <sup>244</sup>Cm, <sup>246</sup>Cm and <sup>248</sup>Cm," Nuclear Science and Engineering, 89, 293-304, 1985.
  - Danon, Y., Slovacek, R.E., Block, R.C., Lougheed, R.W., Hoff, R.W. Moore, M.S., "Fission Cross-Section Measurements of <sup>247</sup>Cm, <sup>254</sup>Es and <sup>250</sup>Cf from 0.1 eV to 80 keV," Nuclear Science and Engineering, 109, 341-349, 1991.





# **RPI Old Gd Loaded Scintillator -1969**

- S. Weinstein, R. Reed, R.C. Block ,Neutron Multiplicity Measurements for <sup>233</sup>U, <sup>235</sup>U and <sup>239</sup>Pu Resonance Fission, Second IAEA Symposium on Physics and Chemistry of fission,IAEA-SM-122/113, 1969.
- Measured neutron multiplicity in a short slowing down time window following a fission event.





ATED PLATES-0.005"AL

he Gaerttner LINAC Center 6

URANIUM-235 FISSION CHAMBER Schematic Diagram = 235U Fisaion Chambe Figure 2.5

Gd loaded Scintillator tank



# Results - 1969



Mechanical, Aerospace and Nuclear Engineering

 Observed fluctuations in <sup>239</sup>Pu neutron multiplicity were used to infer resonance spin states.

Weinstein, S. and Block, R.C., "Neutron Multiplicity-Spin State Correlations for <sup>239</sup>Pu Resonances," Physical Review Letters, Vol. 22, No. 5, 195-198, February, 1969.



### Lead Slowing Down Spectrometers in the US



#### LANL – Proton Driven



#### **RPI** – Electron Driven



#### Why Use a Lead Slowing-down Spectrometer Showing - Lead Slowing-down Spectrometer at RPI

- Tantalum target in the center produces neutrons.
- Neutrons scatter elastically with the Pb.
- •Neutrons can pass through the same position several times.
- About 10<sup>3</sup>-10<sup>4</sup> times higher flux than an equivalent neutron TOF experiment.



Crossed I beam + Li<sub>2</sub>CO<sub>3</sub>





### **Slowing - Down-Time vs. Energy Relation**



-30 -20 -50 -40 -10 0 10 20 30 **40** 50 **60** -60 + 60 60 50 50 40 40 30 30 20 - 20 Y Axis (cm) 10 · 10 0 0 -10 -10 -20 -20 -30 -30 -40 -40 -50 -50 -60 -60 -60 -50 -30 -20 10 20 30 50 -40 -10 40 60 0 X Axis (cm) 

Mechanical, Aerospace and Nuclear Engineering

MCNPX Calculations LANL LSDS 1 proton

**ICLU** The Gaerttner LINAC Center 11

# **LSDS** Applications

- Assay of use nuclear fuel
  - The slowing down spectrum induces fission in the fissile material such as <sup>235</sup>U and <sup>239</sup>Pu
  - To first order the reaction rate as a function of time is a linear combination of the of U and Pu content.
  - Use threshold fission detector with <sup>238</sup>U (indicated some problems in the sub threshold fission of <sup>238</sup>U).
- Fission cross section measurements
- Fission fragment spectroscopy
- $(n,\alpha)$  and (n,p) cross section measurements
- Capture cross section measurements

# The LSDS is a high flux environment which requires appropriate detector development





#### LSDS - Fission cross section measurement example



Mechanical, Aerospace and Nuclear Engineering

Hemispherical fission ion chamber reduces alpha particle pileup



Danon, Y., Slovacek, R.E., Block, R.C., Lougheed, R.W., Hoff, R.W. Moore, M.S., "Fission Cross-Section Measurements of <sup>247</sup>Cm, <sup>254</sup>Es and <sup>250</sup>Cf from 0.1 eV to 80 keV," Nuclear Science and Engineering, 109, 341-349, 1991.



### Simultaneous Measurements of Fission Cross Section and Fission Fragment Mass and Energy Distributions of Small Samples

- Use a double gridded fission chamber with the RPI LSDS
- Use kinematics to compute
  - Fragment angle relative to the normal to the sample
  - Fragment energy distribution
  - Fragment mass distribution
- Future improvements
  - Improve by converting to digital electronics (next slide)
    - Enables more flexibility in the data analysis
- Advantages
  - Low mass samples <40µg)</li>
  - High data throughput (<8h for above mass)</li>

C. Romano, Y. Danon, R. Block, J. Thompson, E. Blain, E. Bond, "Fission Fragment Mass And Energy Distributions As A Function of Neutron Energy Measured In A Lead Slowing Down Spectrometer", Phys. Rev. C, 81, 014607 (2010).









# **Electronics and DAQ**

VME based system with preamplifiers near the LSDS







# **Thin Samples**

#### 34 mg sample of <sup>239</sup>Pu made at INL



#### Sample Frame

- 2500 A thick polyimide
- 1.5 cm aperture
- Made by Luxel Corporation

#### Actinide Sample is made by dissolving actinide in acid and dropping measured amounts on the film

- 25 μg<sup>235</sup>U sample made at LANL
- 0.41 ng <sup>252</sup>Cf made at RPI





### **Fragment Mass and Energy**

Iterative procedure to find the preneutron and postneutron mass and energy



### <sup>252</sup>Cf Contour Plot of TKE vs Fragment Mass









#### Results – Fission Fragment Energy Distribution $E_n < 0.1 \text{ eV}$



### **Fission symmetry in resonance clusters**



K. T. Faler, R. L. Tromp, Phys. Rev. **131**, 1746-1748(1963). R. Nasuhoglu, et al., Phys. Rev. **108**, 1522 (1957).





#### **Fitting the fission modes**

Several possibilities can be considered for example:



The Gaerttner LINAC Center 22



#### Variations In TKE As A Function of Incident Neutron Energy <sup>235</sup>U

# <sup>239</sup>Pu - Results





# <sup>235</sup>U Fission Cross Section Measured at the Same experiment



### **Results – Measured Fission Cross Section**



# Fission and Capure Cross Section Measurement Using a Gamma Tag

- ➤ 16 optically isolated segments NaI(Tl)
- Located at 25 m flight station
- > 1.0 cm thick B<sub>4</sub>C liner enriched in <sup>10</sup>B (captures scattered neutrons)
- Each event categorized by TOF channel, multiplicity, & total γ energy group (up to four groups)



# Samples

<sup>235</sup>U: Multiple <sup>1</sup>/<sub>2</sub>" discs 93% enriched in <sup>235</sup>U
 Additional samples: Depleted U & Au (~ 30mil each)
 Empty sample holder: background subtraction











#### Measurements of <sup>235</sup>U Capture & Fission Yields

- Thermal measurement with enriched <sup>235</sup>U sample
- **16 Segment Multiplicity Detector with 4**  $E_{y}$  groups
- Good agreement with SAMMY calculations
- Extracting Capture Yield from data with mixture of capture and fission events
   BE



- Challenges: Normalization
- Normalize experimental fission yield to thermal point

 $\left|Y_{f}^{ENDF} = k_{1} \cdot Y_{f}\right|$  Solve for  $k_{1} @ 0.0253 \text{ eV}$ 

Use two equations for a predominantly capture resonance and predominantly fission region (thermal)

(a) 11.7 eV res 
$$\left(\frac{\Gamma_{\gamma}}{\Gamma}=0.8\right)$$

 $Y1^{ENDF}$ 

$$= k_2 \cdot Y \mathbf{1}_{\gamma} - k_3 \cdot k_1 \cdot Y \mathbf{1}_f \left[ Y \mathbf{2}_{\gamma}^{ENDF} = k_2 \cdot Y \mathbf{2}_{\gamma} - k_3 \cdot k_1 \cdot Y \mathbf{2}_{\gamma} \right]$$

> Solve the two equations for  $k_2$  and  $k_3$ 





#### <sup>235</sup>U Capture & Fission Yield Data - Epithermal Measurement



### Comparing <sup>235</sup>U Fission and Capture with Evaluations



- Fission is in excellent agreement with evaluations
- Capture data has up to 8% multiple scattering that must be taken into account during the analysis
- Capture yield uncertainty is about 8%
- 0.4-1 keV capture data is closer to ENDF/B-7.0
- 1-2 keV ENDF/B7.0 too high JENDL 4.0 too low.
- E>1 keV data is slightly higher than evaluations but within uncertainties.



### **ORNL SAMMY** fit to <sup>235</sup>U to RPI fission and **Capture Yields**



The Gaerttner LINAC Center 32

# <sup>235</sup>U (n,γ) Low Energy Region







# <sup>235</sup>U (n,γ) High Energy Region



From ORNL 2013 CSEWG presentation





### **Prompt Fission Neutron Spectra**







# **Motivation/Fission Spectra**

- E<sub>emission</sub><0.5 MeV and E<sub>emission</sub>>6 MeV
  - Very little or no experimental data
  - High uncertainty in current models

P. Talou, B. Becker, T. Kawano, M.
B. Chadwick, and Y. Danon,
"Advanced Monte Carlo modeling of prompt fission neutrons for thermal and fast neutron-induced fission reactions on <sup>239</sup>Pu", Phys. Rev. C 83, 064612 (2011).







# **Fission Spectrum Measurement**

- Use the double TOF method
- Use a gamma tag for fission (instead of traditional fission chamber)
- Use a combination of Liquid Scintillators and Li-Glass neutron detectors



# Gamma Tagging

- **Advantages** 
  - Eliminated the need to construct a complicated multiplate fission chamber
  - Simpler sample preparation
  - Can use relatively large samples
  - Can increase the detected fission rate
- Disadvantages
  - False fission detection due to:
    - Random coincidence for radioactive decay
    - Neutron interactions with the gamma detection
    - Beam related:
      - Gamma capture (no neutron emission)
      - Inelastic Scattering (single gamma emitted)
      - Increased background (the biggest problem, use simulations to characterize)





Fast neutrons scattering detector array



# **Experimental Setup**

**EJ-301** 

Gamma

Sample

Position

- Neutron Detectors
  - EJ-204 Plastic Scintillator
    - 0.5" x 5"
    - 47 cm away from center of sample
  - 2 EJ-301 Liquid Scintillators
    - 3" x 5"
    - 50 cm away from center of sample



Mechanical, Aerospace and Nuclear Engineering

- Gamma Detectors
  - 4 BaF<sub>2</sub> detectors on loan from ORNL
  - Hexagonal detectors 2" x 5"
  - 10 cm from center of sample
  - ¼" lead shield between detectors
    - Reducing scattering between detectors



# Gamma Tagging - EJ-204

• Gamma tagging method corrected for 30% detection efficiency compared to 83% detection efficiency with fission chamber



40

# Results

# Will be shown in Zeke Blain's talk





# Summary

- Simultaneous Measurements of Fission Cross Section and Fission Fragment Mass and Energy Distributions of Small Samples.
  - Demonstrated the feasibility of this method
  - Works with small mass sample ~20-40 ug.
  - Data collection with small sample is very quick (<10 hours)</li>
  - Fission cross section can also be measured at the same time
  - Data was obtained for <sup>252</sup>Cf, <sup>235</sup>U and <sup>239</sup>Pu and compares well to other measurements
  - Room for improvement in the DAQ system
- Fission and capture measurements from prompt fission gamma
  - Eliminates the fission detector in the conventional approach
  - Utilize gamma multiplicity and total energy
  - Demonstrated on <sup>235</sup>Ufrom thermal to 2.5 keV
- Fission spectra
  - Demonstrated and characterized the concept of gamma tagging with a <sup>252</sup>Cf sample.
  - Studied the effect of a discriminator on measurements with a fission chamber (applicable to detector calibration with <sup>252</sup>Cf).
  - Performed PFNS measurement <sup>238</sup>U







# Thank You



