






Ordinate scales are % relative standard deviation and nu-bar.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta v/v$ vs. E for $^{226}\text{Ac}(\text{delayed } v)$



Ordinate scale is %
relative standard deviation.




Abscissa scales are energy (eV).

$\Delta v/v$ vs. E for $^{226}\text{Ac}(\text{total } v)$



Correlation Matrix






Correlation Matrix





$\Delta v/v$ vs. E for $^{226}\text{Ac}(\text{delayed } \nu)$




Ordinate scales are % relative standard deviation and nu-bar.


Abscissa scales are energy (eV).

ν vs. E for $^{226}\text{Ac}(\text{delayed } \nu)$





Correlation Matrix





Ordinate scales are % relative standard deviation and nu-bar.

Abscissa scales are energy (eV).



Correlation Matrix

