






Ordinate scales are % relative standard deviation and nu-bar.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta v/v$ vs. E for $^{250}\text{Cf}(\text{delayed } \nu)$



Ordinate scale is %
relative standard deviation.





Abscissa scales are energy (eV).

$\Delta v/v$ vs. E for $^{250}\text{Cf}(\text{total } \nu)$




Correlation Matrix







$\Delta v/v$ vs. E for $^{250}\text{Cf}(\text{delayed } \nu)$





Ordinate scales are % relative standard deviation and nu-bar.

Abscissa scales are energy (eV).





Correlation Matrix





Ordinate scales are % relative standard deviation and nu-bar.

Abscissa scales are energy (eV).



Correlation Matrix

