




Ordinate scales are % relative standard deviation and nu-bar.

Abscissa scales are energy (eV).



Correlation Matrix








Ordinate scale is %  
relative standard deviation.


Abscissa scales are energy (eV).

$\Delta v/v$  vs. E for  $^{241}\text{Cm}$ (total v)





Correlation Matrix





Ordinate scale is %  
relative standard deviation.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta v/v$  vs. E for  $^{241}\text{Cm}(\text{delayed } \nu)$



Ordinate scales are % relative standard deviation and nu-bar.


Abscissa scales are energy (eV).

$\nu$  vs. E for  $^{241}\text{Cm}(\text{delayed } \nu)$





Correlation Matrix





Ordinate scales are % relative standard deviation and nu-bar.

Abscissa scales are energy (eV).



Correlation Matrix

