




Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix




$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,\text{el.})$



Ordinate scale is %
relative standard deviation.

Abscissa scales are energy (eV).


$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,\text{tot.})$



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,\text{el.})$



Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).

σ vs. E for $^{50}\text{Ti}(n,\text{el.})$





Correlation Matrix





Ordinate scale is %
relative standard deviation.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,2n)$



Ordinate scale is %
relative standard deviation.

Abcissa scales are energy (eV).


$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,\text{el.})$



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,np)$



Ordinate scale is %
relative standard deviation.


Abscissa scales are energy (eV).

$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,el.)$



Correlation Matrix







Ordinate scale is %
relative standard deviation.

Abscissa scales are energy (eV).


$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,\text{el.})$



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,p)$



Ordinate scale is %
relative standard deviation.


Abscissa scales are energy (eV).

$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,el.)$





Correlation Matrix






Ordinate scale is %
relative standard deviation.

Abscissa scales are energy (eV).





Correlation Matrix





Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,2n)$



Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


σ vs. E for $^{50}\text{Ti}(n,2n)$



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,n\alpha)$



Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).


σ vs. E for $^{50}\text{Ti}(n,n\alpha)$



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,np)$



Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).

σ vs. E for $^{50}\text{Ti}(n,np)$





Correlation Matrix





Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{50}\text{Ti}(n,p)$




Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).

σ vs. E for $^{50}\text{Ti}(n,p)$





Correlation Matrix





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).



Correlation Matrix

