






Ordinate scales are % relative standard deviation and nu-bar.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta v/v$ vs. E for ^{231}U (delayed ν)



Ordinate scale is %
relative standard deviation.


Abscissa scales are energy (eV).

$\Delta v/v$ vs. E for ^{231}U (total ν)



Correlation Matrix







Ordinate scale is %
relative standard deviation.

Abscissa scales are energy (eV).


$\Delta v/v$ vs. E for ^{231}U (total ν)



Correlation Matrix





$\Delta v/v$ vs. E for $^{231}\text{U}(\text{delayed } \nu)$




Ordinate scales are % relative standard deviation and nu-bar.


Abscissa scales are energy (eV).

ν vs. E for $^{231}\text{U}(\text{delayed } \nu)$





Correlation Matrix





Ordinate scales are % relative standard deviation and nu-bar.

Abscissa scales are energy (eV).



Correlation Matrix

