








Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).





Correlation Matrix






Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).



Correlation Matrix





$\Delta\sigma/\sigma$ vs. E for $^{236}\text{U}(n,2n)$




Ordinate scales are % relative standard deviation and barns.


Abscissa scales are energy (eV).

σ vs. E for $^{236}\text{U}(n,2n)$





Correlation Matrix







Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).





Correlation Matrix





Ordinate scales are % relative standard deviation and barns.

Abscissa scales are energy (eV).



Correlation Matrix

